

Instructions for Linbar[®] and Multibar[®] Part # 104-1, 1304

Fits Dyna Wide Glide from 1991-present.
Will only fit with stock forward controls.

**LINDBY
CUSTOM, INC.**

www.lindbycustom.com

320 E. Crowther Ave., Placentia, CA 92870
Phone (714) 528-0085 • Fax (714) 528-0087

1. Remove forward controls and install the two brackets with the hole pointing forward and down behind the forward controls. Do not tighten bolts yet.
2. Install Linbar / Multibar on the top using 3/8 x 1 1/4 bolt, then install left and right side using 3/8 x 1 1/4 bolt.
3. Tighten all bolts to manufacturer's specifications.

