



LINDBY CUSTOM, INC.

INSTRUCTIONS

**PART # 1202 TWINBAR FIT'S DRESSER, ROADKING
MODELS 1997- PRESENT**

**PART # 1203 TWINBAR FIT'S ROADGLIDE 1998-
PRESENT**

- 1. REMOVE THE STOCK ENGINE GUARD**
- 2. INSTALL THE TOP MOUNT SO THE TOP BRACKET FITS INSIDE THE FRAME, INSTALL THE 5/16" ALLEN BOLT THROUGH THE FRAME AND THEN INTO THE LINBAR. INSTALL THE 2 LOWER 3/8"X16X1 1/4" BOLTS AND THE NYLON LOCK NUTS.**
- 3. MAKE SURE THAT THE BOLTS THERE HOLD THE FLIP DOWN PEGS ARE TIGHT.**
- 4. TIGHTEN ALL BOLTS TO MANUFACTURES SPECIFICATIONS.**